



POK Air Spring

AIR SPRINGS

Contents

follow by POK NO.

Cabin			Seat		
POK Number	Maker	Page	POK Number	Maker	Page
AS02-0001	For RENAULT	3	AS04-0001	For Scania	14
AS02-0002	For RENAULT	3	AS04-0004	For FUSO	14
AS02-0003	For HINO	3	AS04-0025	Universal	14
AS02-0004	For FUSO	4			
AS02-0005	For FUSO	4			
AS02-0006	For FUSO	4			
AS02-0008	For RENAULT	5			
AS02-0009	For HINO	5	Passenger car		
AS02-0010	For VOLVO	5			
AS02-0011	For SCANIA	6	AS10-0001-L	BMW	15
AS02-0012	For FUSO	6	AS10-0001-R	BMW	15
AS02-0013	For FUSO	6	AS10-0002	BMW	15
AS02-0014	For HINO	7	AS10-0003	BMW	15
AS02-0015	For HINO	7	AS10-0005	M-Benz	16
AS02-0016	For HINO	7			
AS02-0017	For ISUZU	8			
AS02-0018	For NISSAN	8			
AS02-0019	For NISSAN	8			
AS02-0020	For VOLVO	9			
AS02-0021	For SCANIA	9			
AS02-0022	For SCANIA	9			
AS02-0023	For ISUZU	10			
AS02-0024	For NISSAN	10			
AS02-0025	For NISSAN	10			
AS02-0026	For NISSAN	11			
AS02-0027	For NISSAN	11			
AS02-0028	For SCANIA	11			
AS02-0029	For SCANIA	12			
AS02-0030	For FREIGHTLINER	12			
AS02-0032	For HYUNDAI	12			
AS02-0033	For HYUNDAI	13			



POK Air Spring

AIR SPRINGS

Contents

follow by Maker

Cabin			Seat		
POK Number	Maker	Page	POK Number	Maker	Page
AS02-0001	For RENAULT	3	AS04-0001	For Scania	14
AS02-0002	For RENAULT	3	AS04-0004	For FUSO	14
AS02-0008	For RENAULT	5	AS04-0025	Universal	14
AS02-0011	For SCANIA	6			
AS02-0021	For SCANIA	9			
AS02-0022	For SCANIA	9			
AS02-0028	For SCANIA	11			
AS02-0029	For SCANIA	12			
AS02-0010	For VOLVO	5	Passenger car		
AS02-0020	For VOLVO	9	AS10-0001-L	BMW	15
AS02-0004	For FUSO	4	AS10-0001-R	BMW	15
AS02-0005	For FUSO	4	AS10-0002	BMW	15
AS02-0006	For FUSO	4	AS10-0003	BMW	15
AS02-0012	For FUSO	6	AS10-0005	M-Benz	16
AS02-0013	For FUSO	6			
AS02-0003	For HINO	3			
AS02-0009	For HINO	5			
AS02-0014	For HINO	7			
AS02-0015	For HINO	7			
AS02-0016	For HINO	7			
AS02-0017	For ISUZU	8			
AS02-0023	For ISUZU	10			
AS02-0018	For NISSAN	8			
AS02-0019	For NISSAN	8			
AS02-0024	For NISSAN	10			
AS02-0025	For NISSAN	10			
AS02-0026	For NISSAN	11			
AS02-0027	For NISSAN	11			
AS02-0030	For FREIGHTLINER	12			
AS02-0032	For HYUNDAI	12			
AS02-0033	For HYUNDAI	13			



POK Air Spring

AIR SPRINGS

CABIN

AS02-0001	For <u>RENAULT</u>	CABIN REAR
	Model: PREMIUM 370 OEM NO. 5010-228-908	

AS02-0002	For <u>RENAULT</u>	CABIN FRONT
	Model: PREMIUM 370 OEM NO. 5010-628-414 5010-629-414	

AS02-0003	For <u>HINO</u>	CABIN FRONT	REAR: AS02-0014
	Model: LSH 2PDA P11C-TK (330PS) LSH K13C-TE (350PS) LSH 1KDF K13C-TV (360PS) LSH 3FDA F20C (340PS / 370PS)	OEM NO. 49710-2250 49710-2251 49710-2252 49710-2253 49710-3363 S50C0-E0030 S4970-02253	



POK Air Spring

AIR SPRINGS

AS02-0004	For <u>FUSO</u>	CABIN FRONT	REAR: AS02-0012
	Model: FP51J 6M70T (380PS) 35T 2006~ OEM NO. MK493369 MK596472 MK493360		
AS02-0005	For <u>FUSO</u>	CABIN FRONT	REAR: AS02-0012
	Model: FP517 6D24T (350PS) S5T 97' OEM NO. MC056299 MK622243-T MK622249		
AS02-0006	For <u>FUSO</u>	CABIN FRONT	
	Model: 6D22T (330PS) FP419 OEM NO. MC096799 MB350657 MC056300 MK622244		



POK Air Spring

AIR SPRINGS

CABIN

AS02-0008	For <u>RENAULT</u>	CABIN FRONT
	Model: PREMIUM 370 OEM NO. 5010-130-797 5010-130-797G	

AS02-0009	For <u>HINO</u>	CABIN FRONT
	Model: LSH 360HP OEM NO. 49710-2222	

AS02-0010	For <u>VOLVO</u>	CABIN REAR
	Model: FL7 - FL 10 OEM NO. 1089728 1594089	



POK Air Spring

AIR SPRINGS

CABIN

AS02-0011	For <u>SCANIA</u>	CABIN FRONT/REAR(without Shock Absorber)
	Model: 94/114/144 R380 (380PS) DC1213 07'~ OEM NO. 1349840	

AS02-0012	For <u>FUSO</u>	CABIN REAR	FRONT: AS02-0005
	FP517 6D24T (350PS) 35T 97' Model: 6M70T (380PS) 6M70T (420PS) OEM NO. MK418574 MK334786 MC056515 MK334675 MK595300 (380PS)		

AS02-0013	For <u>FUSO</u>	CABIN REAR
	Model: 6D22T (330PS) OEM NO. MK996372 MC053766 MC053767 MC053877	



POK Air Spring

AIR SPRINGS

CABIN

AS02-0014	For <u>HINO</u>	CABIN REAR	FRONT: AS02-0003
	Model: LSH P11C-TK (330PS) LSH K13C-TE (350PS) LSH K13C-TV (360PS) LSH 3FDA F20C (340PS / 370PS)	LFS LSH1KDF	
	OEM NO. 52270-1360 52270-1350 52270-1173 52270-1231		

AS02-0015	For <u>HINO</u>	CABIN FRONT
	Model: EH700 LSH E13C-TK (390PS) LSH E13C-TK (420PS) SH1E E13CTK (420PS) 35T 04'	
	OEM NO. 49710-3340 49710-3300 S50C0-E0020	

AS02-0016	For <u>HINO</u>	CABIN REAR
	Model: EH700 LSH E13C-TK (390PS) LSH E13C-TK (420PS) SH1E E13CTK (420PS) 35T 04'	
	OEM NO. 49710-3350 S50D0-E0010 49710-3000	



POK Air Spring

AIR SPRINGS

CABIN

AS02-0017	For <u>ISUZU</u>	CABIN REAR	FRONT: AS02-0023
	Model: GIGA EXR82 6WA1T (360PS) 35T 97'~ OEM NO. 1-52110143-0 1-52110143-1 1-52110143-2		

AS02-0018	For <u>NISSAN</u>	CABIN FRONT	REAR: AS02-0019
	Model: CK450 CK451 PF6TB (380PS) 35T 99'~ OEM NO. 95248-00Z11 95148-00Z11		

AS02-0019	For <u>NISSAN</u>	CABIN REAR	FRONT: AS02-0018
	Model: CW 520 CK451 PF6TB (380PS) 35T 99'~ OEM NO. 95246-00Z12 95246-00Z13		